

PONTOON & FISHING BOAT RENTALS CHECKLIST



MINOCQUA PONTOON CRUISES

Come Explore The Lakes With Us

www.minocquapontooncruises.com

715.892.7777

- Always check gas first
- Check engine oil
- Start engine and check fuel
- Clean carpet
- Garbage
- Top off gas
- Make sure coolers clean
- Cover is stowed or attached to the canopy
- Seats are wiped down/ check for any tears or cigarette burns
- Do the check through with the driver and signer of the Rental Agreement.
- Have the rest of the group load their gear
- Photo copy drivers license and credit card for deposit
- Collect cash or check/ give copy of Rental Agreement
- Gas charge upon return \$4.00 per gallon
- Go over map of the Minocqua chain and give driver laminated navigational map
- Go over Right of Ways and give driver boater reg. handbook
- Time to show the boat to the driver
- Go over control lever and starting/ neutral, forward and reverse
- Go over tilt
- Go over rpms / slow no wake(2000rpm) and maximum (5000rpm)
- Take it easy in Reverse/ max 3000rpm
- Always Clear Prop before backing up or going forward
- Check for Logs, Dogs and Rocks
- Always show the condition of prop to the driver
- Go over life jackets, fire extinguisher, and paddle
- First aid kit/ anchors
- No towing anything
- 100 foot rule
- No over loading boat Keep boat balanced
- No Smoking/ no pets
- Practice docking "away" from the intended dock
- Check for angle of wind and other boats
- Lastly go over operation of canopy or swim ladder
- Give MPC a call if you need anything 715 892 7777